

# 58-330

# Chemical gloves with new AQUADRI™ moisture management technology

# Less sweat equals greater comfort and performance

- AlphaTec AQUADRI gloves are engineered with a unique moisture management technology that keeps hands dryer, for significantly longer periods of time.
- The design features a two-layered coating construction with a superior nitrile film for advanced chemical protection and an inner soft foam coating, helps feeling the difference especially when sweaty hands are a problem, resulting in an improved user comfort and performance.
- Patented AQUADRI technology brings a unique performance in moisture management that significantly reduces sweat build up inside the glove under hot & humid environments.



- Automotive
- Automotive Aftermarket
- Machinery and Equipment
- Metal fabrication
- Chemical

#### **Applications**

- Assembly & inspection of components
- Oil, fluids and filter change
- Painting or cleaning tools or robots
- Plating, coating, sealing, painting
- Handling incoming goods
- Transferring liquids and solids
- Opening and draining pumps valves or lines
- Loading and unloading of proces equipment
- Transferring liquids and solids between vessels and tanks and process equipment
- Opening furnaces draining pumps valves or lines and crackers BTX process
- Cleaning furnaces, distillation pumps, valves or lines and crackers BTX process







# 58-330

### Chemical gloves with new AQUADRI™ moisture management technology

#### **Key Features**

- High performance nitrile compound offers a far superior snag, puncture and abrasion protection compared with rubber or neoprene gloves
- Reverse lozenge palm finish for improved dry/wet grip
- Foldable cuff gutter to prevent dripping on the forearm
- AlphaTec AQUADRI gloves are addressing the most relevant need for the workers: Sweat Reduction; Less Sweat equals Greater Comfort and Performance
- Compliant with FDA food handling requirements
- Also available in vend pack

#### **Vulcanization Chemical Accelerators**

• Zinc Diethyldithiocarbamate

Only a very small number of users may be sensitive to this ingredient(s) and hence may develop irritant and/or allergic contact reactions.

#### **Performance Standards**







EN 374













#### **Technologies**





#### **Specifications**

BRAND   STYLE	DESCRIPTION	SIZE	LENGTH	COLOR	PACKAGE
AlphaTec® 58-330	Aquadri® 2, Nitrile, AQUADRI™	7, 8, 9, 10, 11	320 mm, 12 inches	Green	12 pairs/polybag; 12 polybags/carton

#### Europe, Middle East & Africa Region

Ansell Healthcare Europe NV Ansell Healthcare Europ Riverside Business Park Blvd International, 55 1070 Brussels, Belgium T: +32 (0) 2 528 74 00 F: +32 (0) 2 528 74 01

## Canada Ansell Canada Inc.

105, rue Lauder Cowansville (Québec) J2K 2K8, Canada T: 1800 363-8340 F: 1888 267-3551 North America Region

Ansell Healthcare Products LLC 111 Wood Avenue South, Suite 210 Iselin, NJ 08830, USA T: +1 800 800 0444 F: +1 800 800 0445

Latin America & Caribbean Region

Ansell Commercial Mexico S.A Blvd. Bernardo Quintana No. 7001-0 Blvd. Bernardo Quintana No. 70 Q7001 Torre II. Suites 1304, 1305 y 1306. Col. Centro Sur, c.p. 76079 Queretaro, Qro. Mexico T: +52 442 248 1544 / 248 3133

