

Lovibond® Water Testing Tintometer® Group



PD 250 Set 2 - Total Chlorine

Precise and repeatable dosing of Powder Reagents



- Determination of chlorine according to ISO 7393-2:2017 (free + total)
- 250 tests
- 5 years reagent shelf life (unopened vial)
- Easy handling

Part Number: 194910

Industry

Chemical Industry | Food and Beverage Industry | Industries Others | Marine Industry | Municipalities | Oil and Gas | Pharmaceutical Industry | Power and Energy

PD 250 Set 2 - Total Chlorine

The PD250 is designed for easy and controlled dosage of DPD powder reagents. One click gives the exact amount of reagent required for a 10 ml sample. The PD 250 is the perfect alternative to the Powder Packs for those carrying out a number of tests, saving time while also reducing the amount of packaging waste.

The reagent is supplied in sealed glass vials, sufficient for up to 250 tests. The protective sealing enables a shelf life of up to 5 years although, once the vial has been opened, the contents should be used within 6 months. The vials can be changed quickly and easily. Furthermore, the dispenser can be thoroughly cleaned and the ergonomic design allows for comfort during operation.

Accessories

Title	Part Number
Chlorine Total, 10 ml	530150
VARIO Chlorine Total, 10 ml	530155
Chlorine Free+Total, 10 ml	530160
VARIO Chlorine Free+Total, 10 ml	530165

Delivery Scope

- 1 Powder dispenser „Total Chlorine“
- 1 Reagent vial „Total Chlorine“
- 1 Protective sleeve
- Instruction manual