

TECHNICAL FEATURE

7EG 35GHLE 01 905



The :

- Comfortable and airy surface
- Without staples nor seams
- Abrasion-resistant
- Easily adjustable
- Résiste à un usage intensif

ESD CHAIRS / POLYURETHANE

Chrome, 5-branch, scuff-resistant, reinforced base with antistatic glides
Chrome gas-lift column with height adjustment from 560 to 800 mm and shock absorber
Height adjustable aluminium foot-ring
Ergonomic seat in antistatic black KANGO soft polyurethane
Articulated backrest in antistatic soft polyurethane, adjustable in depth and height
Special conductive polyurethane connects to the metal parts of the chair, allowing electricity to be discharged through carbon castors or pads