

Lovibond® Water Testing Tintometer® Group



TB 250 WL



The TB 250 WL allows easy turbidity measurement in either the field or in the laboratory. Using a „white light“ source and 90° detection, the TB 250 WL meets the specifications for EPA turbidity measurement (EPA Standard 180.1). A power efficient micro-circuit design allows the instrument to yield 5000 tests on 4-AA alkaline batteries with an estimated 7-10 year bulb life. Integrated diagnostics confirm proper operation and accuracy. The instrument features an Auto-Ranging feature that automatically selects the correct turbidity range for your sample. Calibration is simple with the included calibration standards. The instrument comes with all required items for testing including the TB 250 WL Turbidimeter, sample cuvettes, batteries, calibration set, operators manual and carrying case.

- Ideal for regulatory monitoring, process control or field use
- Simple operation
- Easy calibration
- Auto-Ranging

Part Number: 194200

Industry

Chemical Industry | Food and Beverage Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pharmaceutical Industry | Power and Energy

Application

Drinking Water Treatment | Pool Water Control | Waste Water Treatment

TB 250 WL

Thank you for your interest in the TB250 turbidimeter. This instrument is discontinued at this time as we have developed a technologically advanced, portable turbidimeter, the TB350, that will be available in the next few weeks. Please click on the TB350 button below to receive more information.

The TB350 turbidimeter delivers the most reliable measurements for low range to high range samples, without sacrificing accuracy. It is ideal for field applications such as distribution monitoring, environmental samples or customers that test a wide range of samples.

We will continue to support accessories and standards affiliated with the TB250 turbidimeters.

Measuring Range

Test Name	Measuring Range
Turbidity	0.01 - 1100 NTU

Technical Data

Measuring Principle	nephelometric (90° scattered light)
Measuring Range	0,01 bis 1100 NTU
Display	large LCD display
Operation	5 key polycarbonate membrane, splash proof
Auto – OFF	Yes
Power Supply	4 batteries (AA)
Portability	Portable
Environmental Conditions	0 - 50 °C at 0 - 90 % relative humidity (non condensing)
Compliance	CE
Dimensions	95 x 45 x 210 mm
Weight	450 g (Basic unit)
Weight with Packaging	(Basic unit)

Accessories

Title	Part Number
Set turbidity standards T-CAL 0.02, 10, 1000 NTU for TB250 WL in plastic box	194280
Set turbidity standards T-CAL 0.02, 10, 1000 NTU for TB250 WL, refill pack	194281
Sample cuvettes with black lid, set of 3	194290
Silicon oil	194295
Cleaning cloth	197635
Membrane filter set for use when preparing samples, 25 membrane filters 0.2 µm, 2 syringes 20 ml	366170
T-CAL®-Standard, 4000 NTU, 125 ml	48012912
T-CAL®-Standard, 4000 NTU, 500 ml	48012950

Delivery Scope

- White light source
- Range 0.01 – 1100 NTU according to USEPA-approval
- 2 sample vials
- 3 turbidity standards
- 4 batteries
- Instruction manual
- Warranty information

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
sales@lovibond.com
www.lovibond.com
Germany

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
Fax: +44 (0)1980 625412
sales@lovibond.uk
www.lovibond.com
UK

Tintometer China

9F, SOHO II C.
No.9 Guanghualu,
Chaoyang District,
Beijing, 100020
Customer Care China Tel.: 4009021628
Tel.: +86 10 85251111 Ext. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer South East Asia

Unit B-3-12, BBT One Boulevard,
Lebuh Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@lovibond.us
www.lovibond.com.br
Brazil

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.us
USA

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@lovibond.in
www.lovibondwater.in
India

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain